



Locomotive Release from Shop Form
To be completed on every engine released from the Shop

I have reviewed the work packet for locomotive 8525 on this date 8-29-11 and take no exception to applicable laws, rules and or MMA standards, policies and standards.

Oil Sample - L. Dany

B-23, B-39, C), GP-7 MO3 INSPECTION

G. IF THE SEAT MOVEMENT IS IMPEDED, REMOVE SEAT CUSHION AND INSPECT SEAT PAN ROLLER TRACK FOR DEBRIS, MALFUNCTION, OR LACK OF LUBRICATION.	
H. INSPECT SEAT RAILS AND REPLACE IF DAMAGED OR WORN BEYOND PROVIDING SECURE, STABLE MOUNTING OF SEAT.	
I. INSPECT THE FORE/AFT SEAT POSITIONING TRACK. INSPECT THE SEAT RAILS AND REPLACE IF DAMAGED OR WORN BEYOND PROVIDING SECURE, STABLE MOUNTING OF SEAT.	
J. LUBRICATE THE SEAT RAILS WITH SILICONE LUBRICANT.	
K. INSPECT THE BACKREST RAKE ADJUSTMENT KNOB. VERIFY THAT THE KNOB ROTATES EASILY TO ADJUST BACKREST ANGLE.	
L. INSPECT KNOB FOR CRACKS OR SPLITS AND THAT IT IS SECURELY FASTENED.	
M. INSPECT GEAR MECHANISM FOR ANY WEAR OR DAMAGE.	
N. ENSURE THAT THE BACKREST MECHANICAL STOP IS INTACT AND FUNCTIONS AS INTENDED-- PREVENTS THE SEAT BACKREST FROM RECLINING BEYOND APPROXIMATELY 45 DEGREES BACKWARDS FROM A VERTICAL POSITION.	
O. INSPECT THE LUMBAR SUPPORT ADJUSTMENT LEVER. VERIFY THAT THE ADJUSTMENT LEVER OPERATES EASILY TO ADJUST THE LUMBAR SUPPORT.	
P. VERIFY ALL ARMREST FASTENERS ARE SECURE. REPLACE ANY MISSING OR STRIPPED OUT FASTENERS.	
Q. INSPECT ARMREST SWIVEL FASTENERS. ENSURE SWIVEL FASTENER IS SECURE ON EACH ARMREST SUCH THAT THE ARMREST IS WITHOUT SIDE TO SIDE MOVEMENT. ARMREST SHOULD SWIVEL TO VERTICAL. ARMREST SHOULD NOT DROP DOWN PAST IT'S ORIGINAL STOP.	
R. INSPECT SEAT FABRIC ON SEAT PAN AND BACKREST. INSPECT FOR RIPS, TEARS, OR HOLES. SEAT PAN OR BACKREST COMPONENT MAY BE REPLACED IF THERE IS AN EXCESSIVE RIP, TEAR, OR HOLE.	
SEAT PART NUMBERS: Cab Seat, Freight with arms: 2043511 Cab Seat Mid Back: 20425731 Wall Mounted Pedestal: 20435541 Trunion Pedestal Assembly: 20425721 Seat Pedestal Rail Left Side 65": 20422211 Seat Pedestal Rail Right Side 46": 20422221	
INSPECT AND REPAIR AS REQUIRED:	
A. CAB / CARBODY/DOORS/HINGES/WINDOWS/LATCH SEALS/WEATHER STRIPPING AND SEALS/MIRRORS. ALSO LUBRICATE/CHANGE AS NEEDED	
A. CLEAN THE CAB, WINDOWS, AND EQUIPMENT	
COMPLETE WINTERIZATION SHEET (AUGUST - APRIL)	
WASH LOCOMOTIVE ENGINE/ENGINE ROOM/AND AIR COMPRESSOR ROOM	
WASH THE LOCOMOTIVE	

B-23, B-39, C-30, GP-7 MO3 INSPECTION

Revision Date: 8/18/2010
 Issued By: Tim Scalfia



Electrical in House

WORKED BY:

SERVICE THE BATTERIES AND COMPLETE JSP-010

VERIFY EVENT RECORDER IS WORKING

CHECK & RECORD THE DATE ON HEAD END DEVICE 1-12-11

COMPLETE THE HEAD END DEVICE CONNECTOR SHEET

CHECK THE FOLLOWING EQUIPMENT AND THEIR RELATED GUARDS AND LENSES FOR PROPER OPERATION:

CHECK ALL GROUND AND STEP LIGHTS, FRONT AND REAR HEADLIGHTS, DITCH LIGHTS, CAB LIGHTS, GAUGE LIGHTS, NUMBER PLATES, PLATFORM LIGHTS, ALL WARNING AND INDICATOR LIGHTS

TRACTION MOTORS AND UNDERFRAME

CHECK THE TRACTION MOTOR LEADS, VERIFY NO LEADS ARE RUBBING ON THE FRAME

INSPECT TRACTION MOTOR COVERS AND ENSURE BOLTS ARE IN PLACE AND TIGHT

CHECK M.U. RECEPTACLE PINS AND LIDS. MAKE NECESSARY REPAIRS

MAKE SURE M.U. CABLES DO NOT FOUL COUPLERS

J. Hest
J. Hest
J. Hest

J. Hest

J. Hest

J. Hest
J. Hest

B-23, B-39, C-30, GP-7 MO3 INSPECTION



Out Bound Loadtest Electrical/Mechanical

WORKED BY:

ELECTRICAL - OUT Bound

- VERIFY THE OPERATION OF THE GROUND RELAY
- CHECK FOR LOW VOLTAGE GROUNDS (7 watt bulb)
- WHILE IN THROTTLE 3 LOAD TEST, CHECK FOR AC GROUNDS
- CHECK OPERATION OF:
 - A. HEATING
- COMPLETE THE IN-BOUND LOAD TEST SHEETS
- GROUND RELAY-(TEST THREE TIMES TO VERY LOCK-OUT)(DYNAMIC & POWER)
- CHECK THE FOLLOWING FOR PROPER OPERATION:
 - A. CREW ALERT
 - B. RADIO AND ANTENNA
 - C. AXLE ALT. SPEEDO
 - D. MU ENGINE SHUTDOWN
 - E. FUEL CUT-OFF
 - F. TEST WARNING DEVICES

J. Hest
J. Hest
J. Hest
J. Hest
J. Hest
J. Hest

MECHANICAL

- CLEAN AND SERVICE TOILET AND RESTROOM
- DRAIN RETENTION TANK
- PROPER LUBRICATION? FUEL LEAKS? CAM ROLLER ROTATION? ETC.
- INSPECT FUEL SYSTEM HOSES AND PIPES FOR LEAKS
- INSPECT COOLING SYSTEM:
 - A: CHECK HOSES AND PIPES FOR LEAKS
- CHECK OPERATION OF ENGINE PROTECTION DEVICES:
 - A. CRANKCASE PRESSURE
- VISUALLY INSPECT AIR COMPRESSOR FOR WATER, AIR OR OIL LEAKS
- PERFORM MANUAL AIR BRAKE TEST
- Verify Flow Gauge
130 main reservoir is 64 + or - 3,
reservoir is 60 + 0
- PERFORM PENALTY BRAKE TEST
- CHECK FOR CORRECT AIR PRESSURE SETTINGS:
 - A. MAIN RESERVOIR (130 - 140 PSI)
 - B. BRAKE PIPE (90 PSI)
 - C. EQUALIZING RESERVOIR (90 PSI)
 - D. BRAKE CYLINDER (72 - 74 PSI)
 - E. COMPRESSOR CONTROL (130 - 140 PSI +/-5 PSI)
- CHECK FLUID LEVELS BEFORE LOADING:
 - A: ENGINE OIL
 - B: COOLING WATER
 - C: AIR COMPRESSOR OIL
- TEST OPERATION OF THE FOLLOWING DEVICES:
 - A. BELL
 - B. SANDERS (FORWARD, REVERSE, EMERGENCY)
 - C. RADIATOR SHUTTERS

K.B. K. Husey
DB
DB
DB
DB
DB
DB
DB

NOTE: 120-130-140 main

K. Husey

Changed out oil filters } K. Husey
" Fuel filter }

Service Operations

THROTTLE 8 OUTBOUND LOAD TESTS

UNIT _____

DATE _____

Eng RPM (900)	EMD	<u> </u>	Lube Oil Pres	<u> </u>
Eng RPM (1050)	GE	<u>1050</u>	Water Temp	<u>185</u>
Horsepower		<u>3722</u>	Overspeed Setting	<u>1090</u>
Volts (5.3)	B-23	<u> </u>	RACK SETTING	<u>24 1/2</u>
Volts (7)	C-30	<u> </u>		
Volts (720)	B-39	<u>700</u>		

THROTTLE #1 STALL TEST

OP Mode	(PWR)	<u>F</u>	
AMPS	(300)	<u>300</u>	
MGA	(1220)	<u>3837</u>	NOT APPLICABLE TO B-23 AND C-30
Charging Rate	(70v)	<u>74</u>	

IN BOUND

- SETT LOAD

AMPS - 3762 - Ki Hany

HPower - 3701

VOLTS - 688

Dump toilet

Fuel unit - Ki Hany

LOCOMOTIVE										DATE				
8525										8-29-11				
Start Readings					Has Shims		END READING					Has Shims		OLD GAUGE
	Flange Height	Flange Thickness	Rim Thickness	Witness Grove	YES	NO		Flange Height	Flange Thickness	Rim Thickness	Witness Grove	YES	NO	FLANGE THICKNESS MEASUREMENT
L#1	0-18	0-0	46				L#1							0-on 0-1-17/64"
L#2	0-19	0-0	46				L#2							1-on 0-1-15/64"
L#3	0-19	0-0	48				L#3							2-on 0-1-7/32"
L#4	0-19	0-0	48				L#4							3-on 0-1-5/32"
L#5							L#5							4-on 0-1-7/64"
L#6							L#6							5-on 0-1-3/64"
														6-on 0-1-1/32"
														7-on 0-63/64"
														8-on 0-15/16"
R#1	0-19	0-0	46				R#1							0-on 0-1"
R#2	0-19	0-0	46				R#2							0-on 1-1-1/16"
R#3	0-19	0-0	48				R#3							0-on 2-1-1/8"
R#4	0-19	0-0	48				R#4							0-on 3-1-3/16"
R#5							R#5							0-on 4-1-1/4"
R#6							R#6							0-on 5-1-5/16"
														0-on 6-1-3/8"
														2-on 6-1-13/32"
														4-on 6-1-7/16"
														6-on 6-1-31/64"

WEAR LIMITS FOR ROAD & SWITCH LOCOMOTIVES - MINIMUM DAILY REQUIREMENTS

FRA 1 1/2" MMA 1 7/16" Flange Height
 FRA 7/8" MMA 15/16" Flange Thickness
 FRA 1" MMA 1 1/16" Rim Thickness
 FRA 5/16" MMA 1/4" Tread Wear

FLANGE HEIGHT MEASUREMENT

WEAR LIMITS - ROAD & SWITCH LOCOS - MIN. 92 DAY REQ

WEAR LIMITS - PASSENGER LOCOS - MIN 92 DAY REQ

FLANGE HEIGHT	Flange THICKNESS	Rim THICKNESS	Tread WEAR	Flange HEIGHT	Flange THICKNESS	Rim THICKNESS	Tread WEAR
FRA 1 1/2"	FRA 7/8"	FRA 1"	FRA 5/16"	FRA 1 1/2"	FRA 7/8"	FRA 1"	FRA 5/16"
MMA 1 7/16"	MMA 1 1/32"	MMA 1 1/8"	MMA 1/4"	MMA 1 7/16"	MMA 1"	MMA 1 1/4"	MMA 1/4"

CONVERSION CHART FOR WHEEL DIAMETER

8=	37"	15=	37 7/8"	22=	38 1/2"	29=	39 5/8"	36=	40 1/2"
9=	37 1/8"	16=	38"	23=	38 7/8"	30=	39 1/4"	37=	40 5/8"
10=	37 1/4"	17=	38 1/8"	24=	39"	31=	39 7/8"	38=	40 3/4"
11=	37 3/8"	18=	38 1/2"	25=	39 1/8"	32=	40"	39=	40 7/8"
12=	37 1/2"	19=	38 3/8"	26=	39 1/4"	33=	40 1/8"	40=	41"
13=	37 5/8"	20=	38 1/2"	27=	39 3/8"	34=	40 1/4"	41=	41 1/8"
14=	37 3/4"	21=	38 5/8"	28=	39 1/2"	35=	40 3/8"	42=	41 1/4"

LOCOMOTIVE RAIL CLEARANCE

COUPLER HEIGHT	FRONT	PILOT HEIGHT	FRONT	HEIGHT OF HORIZONTAL END HANDHOLD OR UNCOUPLING LEVER IF USED AS HORIZONTAL HANDHOLD	LOCO RAIL CLEARANCE
FRA	MAX 34 1/2" MIN 31 1/2"	FRA	MAX 6" MIN 3"	5	FRA MIN 2 1/2"
MMA	MAX 34 1/2" MIN 32 1/2"	MMA	MAX 6" MIN 3 1/2"	4 3/4	MMA MIN 3"

WHEEL DIAMETER MEASUREMENTS ARE TAKEN FROM THE TOP OF THE WITNESS GROOVE 40" DIAMETER WHEELS WITNESS GROOVE = 36".

42" DIAMETER WHEEL WITNESS GROOVE = 38"

WHEEL MATCHING STANDARDS FOR 6 AXLE LOCOMOTIVES (FRA & MMA STANDARDS ARE THE SAME)

3/4" IS THE MAXIMUM VARIATION ALLOWED, IN WHEEL DIAMETER, BETWEEN ANY 2 WHEELS IN THE SAME TRUCK WITHOUT SHIMS.

1 1/4" IS THE MAXIMUM VARIATION ALLOWED, IN WHEEL DIAMETER, BETWEEN ANY 2 WHEELS IN THE SAME TRUCK WITH SHIMS APPLIED.

1 1/2" IS THE MAXIMUM VARIATION ALLOWED, IN WHEEL DIAMETER, BETWEEN ANY 2 WHEELS ON DIFFERENT TRUCKS.

NOTE: WHEN FIGURING THE DIFFERENCE IN WHEEL DIAMETER, TO DETERMINE IF SHIMS ARE REQUIRED, YOU MUST USE THE AVERAGE WHEEL DIAMETER FIGURES

REMEMBER THIS RULE

0 TO 5 DIAMETER DIFFERENCE NO SHIMS REQUIRED 6 TO 10 DIAMETER DIFFERENCE ADD APPROPRIATE SHIMS TO BOTH BOXES ON BOTH SIDES OVER 10 IN DIAMETER DIFFERENCE REQUIRES WHEEL CHANGE OR TRUED

NOTE: ON EMD LOCOMOTIVES USE ONLY ONE 1/2" SHIM EMD PART NUMBER 8455981 SHELLED TREAD AND FLAT SPOTS MUST BE TRUED OR CHANGED WHEN FOUND ON PERIODIC OR UNSCHEDULED MAINTENANCE. KCS CONDEMNING LIMITS FOR SHELLED TREAD ON A SERVICE TRACK

• ONE SHELLED SPOT 1" OR GREATER IN LENGTH • ONE SHELLED SPOT WITH A DEPTH OF 1/4" OR MORE.

EMPLOYEES SIGNATURE

D. Black

SUPERVISORS SIGNATURE

JSP-010 (BATTERY MAINTENANCE AND QUALIFICATION)

JOB SPECIFIC PROCESS

Locomotive Type: ALL MODELS
Valid for Road Numbers: (All Models)

Overview: This job process sheet will assist with the maintenance and qualification of batteries.

SPECIAL TOOLS OR EQUIPMENT:

SEQUENCE OF JOB STEPS	Please print your name, NO signatures
1. Ensure the locomotive is shutdown, discharged, all of the circuit breakers are open and the battery knife switch is open.	J. Hart
Battery Qualification/Maintenance	
2. NOTE: If batteries are dead, connect the charger until the charge rate falls below 10 amps to determine state of charge. Readings under 20 V are suspect for units with just 2 batteries.	
3. Insert hose stem into battery cell and squeeze bulb.	
4. Release pressure until enough acid solution is drawn into the tube allowing the float to float freely. Be sure float does not touch rubber stopper at the top of the tube.	
5. The float reading at the water line is the uncorrected charge level of the battery.	
6. Read and record the specific gravity of all 16 pilot cells. "record readings below": acceptable range is 1.225 – 1.300 (if out of this range notify tech support) Note 1: the sheet below is set up for 2 or 8 batteries as some units have 8 batteries. Note 2: accurate readings cannot be obtained if water has recently been added to cells. Differences of 50 points or more between readings in battery cells may indicate pending battery failure.	
7. Based on the above specific gravity readings, do any batteries need replaced? Remember, if the unit came in with already dead batteries, an attempt to charge the batteries must be made before taking the specific gravity readings. YES	
8. Return acid to cell from which it was drawn.	
9. Be sure all vent plugs are replaced and tight.	
10. With Unit shut down measure the voltage reading across each battery at the terminals, record readings on the chart below.	
11. Make a general check of the battery as to proper blocking, clean and tight connections at all points, and any unusual appearance or condition. If any unusual appearance or conditions exist, like corrosion, clean with scotch-brite buffer or wire br	
12. Apply approved protective coating to connections after terminals are cleaned and dried	
13. Add water as required (Add water to bottom of filler neck).	
Battery Cranking Voltage Test	
14. Close battery knife switch, and circuit breakers.	
15. Open the injector toggle switch, on EUI units to prevent unit from starting.	
<p>NOTE: Battery cranking voltage readings do not need to be taken on Air Start Locomotives.</p>	

16. On MUI engines, pull the Governor button and hold back the Lay-shaft while cranking the engine over to prevent unit from starting.

18. Based on the cranking voltages, is any battery suspect of needing replaced? YES NO

2 Battery Units	Specific Gravity				Water Added			Battery Replaced-Reason
	Cell 1	Cell 2	Cell 3	Cell 4	Yes	No	Yes	
Battery 1								o
Section A	1250	1250	1250	1250		✓		
Section B	1250	1250	1250	1250		✓		
Section C	1250	1250	1250	1250		✓		
Section D	1250	1250	1250	1250		✓		

2 Battery Units	Specific Gravity				Water Added			Battery Replaced-Reason
	Cell 1	Cell 2	Cell 3	Cell 4	Yes	No	Yes	
Battery 2								o
Section A	1250	1250	1250	1250		✓		
Section B	1250	1250	1250	1250		✓		
Section C	1250	1250	1250	1250		✓		
Section D	1250	1250	1250	1250		✓		

8 Battery Units	Specific Gravity				Water Added			Battery Replaced-Reason
	Cell 1	Cell 2	Cell 3	Cell 4	Yes	No	Yes	
Battery 1								
Battery 2								
Battery 3								
Battery 4								
Battery 5								
Battery 6								
Battery 7								
Battery 8								

BATTERY CRANKING VOLTAGE CHART

	Battery 1	Battery 2	Battery 3	Battery 4	Battery 5	Battery 6	Battery 7	Battery 8
Battery Voltage	34.0	34.0						
Battery Voltage								

	Battery 1	Battery 2	Battery 3	Battery 4	Battery 5	Battery 6	Battery 7	Battery 8
Cranking Battery Voltage								
Battery Voltage								

	Battery 1	Battery 2	Battery 3	Battery 4	Battery 5	Battery 6	Battery 7	Battery 8
Cranking Battery Voltage								

Unit: _____

Date: _____

DEFECTS FOUND DURING INSPECTION

DEFECT <u>Toilet real dirty</u>	INSPECTED BY: <i>[Signature]</i>
REPAIR <u>Pump & washed</u>	CORRECTED BY: <i>[Signature]</i>

DEFECT _____	INSPECTED BY: _____
REPAIR _____	CORRECTED BY: _____

DEFECT _____	INSPECTED BY: _____
REPAIR _____	CORRECTED BY: _____

DEFECT _____	INSPECTED BY: _____
REPAIR _____	CORRECTED BY: _____

DEFECT _____	INSPECTED BY: _____
REPAIR _____	CORRECTED BY: _____

Unit: _____

Date: _____

DEFECTS FOUND DURING INSPECTION

DEFECT _____ _____ _____	INSPECTED BY: _____
REPAIR _____ _____ _____	CORRECTED BY: _____

DEFECT _____ _____ _____	INSPECTED BY: _____
REPAIR _____ _____ _____	CORRECTED BY: _____

DEFECT _____ _____ _____	INSPECTED BY: _____
REPAIR _____ _____ _____	CORRECTED BY: _____

DEFECT _____ _____ _____	INSPECTED BY: _____
REPAIR _____ _____ _____	CORRECTED BY: _____

DEFECT _____ _____ _____	INSPECTED BY: _____
REPAIR _____ _____ _____	CORRECTED BY: _____

Description of Work Performed

Locomotive ID _____

Time Started _____

Time Finished _____

Manufacturer is QEI Version # S45E
Serial Number is 0204110402
Customer is MMAR

Data was removed on - 07:34:16 on 08/30/11
Last Downloaded on - 12:42:00 on 08/04/11
Battery was installed on - 11/12/04
Locomotive Number is - 8525

Downloaded by - jh
Location - derby
Train - 234
Wheel Size Entry - 39
Wheel Size used by program:
Circumference = 122.5 Diameter = 39.0
No memo present.

Wheel size used for printout is 122.52

QDP Version V



Quantum Desktop Playback
Data Scan Report

Report Date: 08-30-2011
Locomotive 8525

Data Removed on 08-30-11

SPEED (MPH)	OK
TRACTION MOTOR CURRENT	OK
BRAKE PIPE PRESSURE	OK
INDEPENDENT BRAKE	OK
END-OF-TRAIN PSI	Never above 20.
EP BRAKE REQUESTED	Never ON/ACTIVE
THROTTLE	Low Idle never reported.
REVERSE	OK
EIE	OK
PCS	OK
HORN	OK
EOT MOVING	Never ON/ACTIVE
EOT MSG. JUST RX	Never ON/ACTIVE
EOT LIGHT	Never ON/ACTIVE
EP OPERATING MODE	Never ON/ACTIVE
EP PENALTY BRAKE	Never ON/ACTIVE
EP ENGINEER EMERGENCY	Never ON/ACTIVE









Montreal, Maine, & Atlantic Railway
Locomotive

Unit 8525

Date 8-30-11

3 Month Federal Air Work

Signature

1. Inspect and repair air piping and valves for leaks 
2. Test all air gauges with gauge tester and set if required..... 
3. With full brake pipe pressure, make a 20lb. reduction, move the cutoff valve to "OUT" position and move the lead - dead valve to "DEAD" position. Brakes must remain applied for 5 minutes..... 
4. Cover each trainline hose coupling with hand and test for leakage through valve, then apply blank dummy couplings to the trainline hoses on each end of the unit and open trainline valves. Make a 20lb. reduction with the Automatic, move the cutoff valve to "OUT" position and check for brake pipe leakage. Leakage shall not exceed 5 lb. per minute..... 
5. Reduce main reservoir pressure to 85 lbs. by draining #2 main reservoir. (*) Check cab gauge for leakage from main reservoirs and piping for 3 minutes. Leakage must not exceed an average of 3 lb. per minute during the test..... 
6. Drain #1 main reservoir (*) completely and test check valve between reservoirs. Pressure should remain on the main reservoir gauge in the cab as #1 main reservoir is drained..... 
7. Check all MU valve handles to ensure the locking devices work properly. Lubricate or replace as necessary..... 
8. Check knuckle thrower to make sure it opens the knuckle. Lubricate or repair as necessary..... 

Note (*) #1 reservoir is without the check valve. #2 is with the check valve.

probe all brake cyl - K. Hays